



FARM COMMERCIAL DRAG CONVEYOR

**9EF, 14EF, 20EF MODELS
ASSEMBLY & OPERATION**



Read this manual before using product. Failure to follow instructions and safety precautions can result in serious injury, death, or property damage. Keep manual for future reference.

Part Number: EFDCM0410 R1

Revised: Jun/17

TABLE OF CONTENTS

1. Introduction	5
2. Safety First.....	7
2.1. General Safety	8
2.2. Assembly Safety.....	9
2.3. Operational & Maintenance Safety.....	10
2.3.1. Lockout and Tagout Procedures	10
2.4. Safety Decal Locations.....	11
2.4.1. Decal Installation	11
2.4.2. Decal Locations	11
3. Installation	13
3.1. Check Shipment	13
3.2. Lifting and Moving	13
3.3. Assembly	13
3.4. Installation	14
3.5. Motor Mounts Drag Conveyor Assembly.....	15
3.6. Installation for Torque-Arm II Speed Reducer	17
3.6.1. Torque-Arm II Bushing Installation	19
3.7. Torque-Arm II Belt Guard Installation	20
4. Operation	23
4.1. Pre-Operation	23
4.2. Start-Up	23
4.3. General.....	24
5. Maintenance	25
5.1. Torque-Arm II Speed Reducer Maintenance.....	26
5.1.1. Bushing Removal for Standard Taper Bushings	26
5.1.2. Lubrication	26
5.2. Drag Conveyor Extended Shutdown/Storage	28
5.3. Torque-Arm II Speed Reducer Storage.....	28
6. Troubleshooting	31
Limited Warranty	33

1. Introduction

Union Iron Drag Conveyors are tough, dependable, and provide efficient handling capacity for conveying a wide variety of bulk materials with minimum product degradation.

The flat bottom design increases conveying capacity, and special Union Iron features substantially reduce the product-to-product contamination that you find with other designs. Product features include:

- Rugged, heavy-duty steel construction for durability in the most demanding applications.
- Dust and weather-tight construction to maintain product quality against the elements and prevent dust from escaping.
- UHMW polyethylene flights to reduce metal-to-metal contact and provide quiet, efficient operation.
- Replaceable bottoms and side liners.
- Head and tail are equipped with removable end plates to facilitate maintenance.

Before using the Drag Conveyor, give this manual to the people who will be operating and maintaining this equipment. Reading and understanding the manual will reduce downtime and equipment failure, as well as ensure safe and efficient operation. A sign-off form is provided on the inside front cover for your convenience.

The serial number plates are located on the head assembly side plate on the opposite side of the drive, and on the tail assembly side plate. Please mark the number in the space provided for easy reference.

Model#	
Serial #	
Production Year	

2. Safety First



The Safety Alert symbol to the left identifies important safety messages on the product and in the manual. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety messages. Why is SAFETY important to you?

Three big reasons:

- Accidents disable and kill.
- Accidents cost.
- Accidents can be avoided.

SIGNAL WORDS

Note the use of the signal words **DANGER**, **WARNING**, **CAUTION**, and **NOTICE** with the safety messages. The appropriate signal word for each message has been selected using the definitions below as a guideline.

The Safety Alert symbol means ATTENTION, BE ALERT!, YOUR SAFETY IS INVOLVED.

DANGER	
	Indicates an imminently hazardous situation that, if not avoided, will result in serious injury or death.
WARNING	
	Indicates a hazardous situation that, if not avoided, could result in serious injury or death.
CAUTION	
	Indicates a hazardous situation that, if not avoided, may result in minor or moderate injury.
NOTICE	
	Indicates a potentially hazardous situation that, if not avoided, may result in property damage.

2.1. GENERAL SAFETY

Important: *The general safety section includes instructions that apply to all safety practices. Any instructions specific to a certain safety practice (e.g., assembly safety), can be found in the appropriate section. Always read the complete instructional sections and not just these safety summaries before doing anything with the equipment.*

YOU are responsible for the **SAFE** use and maintenance of your equipment. **YOU** must ensure that you and anyone else who is going to work around the equipment understands all procedures and related **SAFETY** information contained in this manual.

Remember, **YOU** are the key to safety. Good safety practices not only protect you, but also the people around you. Make these practices a working part of your safety program.

- It is the equipment owner and the operator's responsibility to read and understand **ALL** safety instructions, safety decals, and manuals and follow them before assembling, operating, or maintaining the equipment. All accidents can be avoided.
- Equipment owners must give instructions and review the information initially and annually with all personnel before allowing them to operate this product. Untrained users/operators expose themselves and bystanders to possible serious injury or death.
- Use this equipment for its intended purposes only.
- Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety, and could affect the life of the equipment. Any modification to the equipment voids the warranty.
- Do not allow children, spectators, or bystanders within the work area.
- Have a first-aid kit available for use should the need arise, and know how to use it.
- Provide a fire extinguisher for use in case of an accident. Store in a highly visible place.
- Wear appropriate protective gear. This list includes, but is not limited to:
 - a hard hat
 - gloves
 - protective shoes with slip-resistant soles
 - protective goggles
 - hearing protection
- For Powered Equipment: before servicing, adjusting, or repairing powered equipment, unplug, place all controls in neutral or off position, stop the engine or motor, remove ignition key or lock out power source, and wait for all moving parts to stop.



- Follow good shop practices:
 - keep service area clean and dry
 - be sure electrical outlets and tools are properly grounded
 - use adequate light for the job at hand
 - Think SAFETY! Work SAFELY!



2.2. ASSEMBLY SAFETY

- Have 2 people handle the heavy, bulky components.
- Check all equipment for damage immediately upon arrival. Do not attempt to install a damaged item.
- If the equipment must have an open housing as a condition of its use and application, it must be guarded by a railing or fence.
- Use **rugged gratings** where necessary. If the distance between the grating and moving elements is less than 4", the grating opening must not exceed 1/2" x 1" (or 1/2" x 2" for hopper gratings). Covers, guards, and gratings at inlet points must be installed so that personnel cannot be injured in any way.
 - Use solid covers that are designed and installed so that personnel is not exposed to accidental contact with any of the equipment's moving parts.
 - Connect inlet and discharge openings to other equipment in order to completely enclose the equipment.
- As required by the applicable laws, standards, and good practice, the purchaser/owner is responsible for:
 - guarding all rotating equipment such as drives, gears, shafts, and couplings
 - purchasing and providing safety devices and controls
- Before power is connected to the drive, perform a pre-start-up safety check to ensure the equipment and area is safe and that all guards are in place and secure.
- Electrical equipment must conform to the National Electric Code or National Electrical Safety Code, including requirements for the environment. Also consider:
 - *Overflow devices* (electrical interlocks) to warn personnel and shut off power when discharge from conveyor is interrupted.
 - *Overload protection* for devices (shear pins, torque limiters, etc.) and *no-speed protection* (zero-speed switches) to shut off power in the event of an incident that might cause the conveyor to stop operating.
 - *Safety shut-off switch* with power lockout provisions at conveyor drive.
 - *Emergency stop switches* that are readily accessible.
 - *Electrical interlocking* to shut down feeding conveyors whenever a receiving conveyor stops.
 - *Signal devices* to warn personnel of imminent start up of conveyor, especially if started from a remote location.

2.3. OPERATIONAL & MAINTENANCE SAFETY

Electrical controls, machinery guards, railings, walkways, arrangement of installation, training of personnel, etc., are necessary for a safe working environment. It is the responsibility of the contractor, installer, owner, and user to supplement the materials and services furnished with the necessary items to make the conveyor installation comply with the law and accepted standards.

- Do not operate conveyors unless all covers/guards are in place.
- Advise all operating personnel of the location and operation of all emergency controls and devices. Maintain clear access to these controls and devices.
- Do not place hands, feet, or any part of your body or clothing in the conveyor.
- Never walk on conveyor covers, gratings, or guards.
- Do not use conveyor for any purpose other than that which it was intended.
- Do not poke or prod material into the conveyor with a bar or stick inserted through the openings.
- Conveyors are not normally manufactured or designed to handle materials that are hazardous to personnel (explosive, flammable, toxic, or otherwise dangerous). However, conveyors may be designed to handle these materials. Also, conveyors are not manufactured to comply with local, state, or federal codes for unfired pressure vessels. If hazardous material is to be conveyed or if the conveyor is to be subjected to internal or external pressure, consult Union Iron prior to any modifications.
- Be aware of hazardous locations where, without protection, people may be injured by contact with conveyor or material. If conveyor blocks a walkway, provide a crossover stairway or ramp for passage of personnel. If installed overhead, minimum clearance should be 7' for safety.
- Handling foodstuff subjects conveyors to special codes for construction, location, and accessibility. Investigate before ordering standard components! Food conveyors often require hinged access doors for drop-bottom trough cleaning, and such doors require special safety controls and procedures by customer to prevent personnel injuries. Extensive use of padlocks, with keys in the hands of only management personnel, is one means frequently used.
- Do not attempt a field modification of conveyor or components.
- Perform frequent inspections of these controls and devices, covers, guards, and equipment to ensure proper working order and correct positioning.

The Conveyor Equipment Manufacturer's Association (CEMA) has produced an audiovisual presentation entitled "Safe Operation of Screw Conveyors, Drag Conveyors, and Bucket Elevators." Union Iron encourages acquisition and use of this source of safety information.

2.3.1. LOCKOUT AND TAGOUT PROCEDURES

To minimize possibility of serious injury or death to workers from hazardous energy release (for example, when restarting the equipment) and prevent worker deaths from all forms of hazardous energy release, follow all lockout and tagout procedures when installing and servicing equipment. Ensure that all OSHA procedures are adhered to; for example:

- De-energize, block, and dissipate all sources of hazardous energy.
- Lock out and/or tag out all forms of hazardous energy.
- Ensure that only 1 key exists for each assigned lock, and that you are the only one that holds that key.
- After verifying all energy sources are de-energized, service or installation may be performed.
- Ensure that all personnel are clear before turning on power to equipment.

For more information on occupational safety practices, see www.osha.gov.

2.4. SAFETY DECAL LOCATIONS


- Keep safety decals clean and legible at all times.
- Replace safety decals that are missing or have become illegible. See decal location figures that follow.
- Replaced parts must display the same decal(s) as the original part.
- Safety decals are available from your distributor, dealer, or factory.

2.4.1. DECAL INSTALLATION

1. Decal area must be clean and dry, with a temperature above 10°C (50°F).
2. Decide on the exact position before you remove the backing paper.
3. Align the decal over the specified area and carefully press the small portion with the exposed sticky backing in place.
4. Slowly peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
5. Small air pockets can be pierced with a pin and smoothed out using the sign backing paper.

2.4.2. DECAL LOCATIONS

Replicas of the safety decals that are attached to the equipment are shown in the figure(s) that follow. Good safety requires that you familiarize yourself with the various safety decals and the areas or particular functions that the decals apply to as well as the safety precautions that must be taken to avoid serious, injury, death, or damage.



DECAL 1 - P200-0016



DECAL 2 - P200-0006



DECAL 4 - P200-0012



DECAL 5 - P200-0018



DECAL 3 - P200-0005

- Place decal 1 in a convenient location on the equipment.
- Place decal 2 on the belt or chain guard.
- Decal 3 is placed behind guards. Place decal 4 on all head, tail, and intermediate section covers, as well as all inspection and access opening covers.
- Place decal 5 on the motor conduit boxes.

3. Installation

Warning: Before continuing, please reread the safety information relevant to this section in the safety section of this manual. Failure to follow the safety instructions can result in serious injury, death, or property damage.

3.1. CHECK SHIPMENT

Immediately check that all items in the shipment have been received and are undamaged (check for bent or dented casing sections, and look over the covers, buckets, chain guards, drives, etc.).

Note: *Mark claims for damaged parts on the shipping papers and immediately file a claim. Do not attempt to install a damaged item.*

3.2. LIFTING AND MOVING

Take extreme care to prevent damage when moving assembled conveyors or components. Spreader bars with slings are the recommended support method for lifting. The unsupported span should be no longer than 10' to 12'.

Never lift a conveyor with only one support point. When choosing supports points for especially heavy items such as drives or gates, consider the weight of an item in relation to load balance and its bending effect.

NOTICE

Lifting the conveyor without proper support could damage the conveyor or components.

3.3. ASSEMBLY




Figure 3.1

is a representative drawing only. It is the responsibility of the purchaser to consult contract drawings for specific items on each conveyor.

For safety and proper operation, drag conveyors must be assembled and erected straight and true. The purchaser is responsible for ensuring all support and mounting surfaces are straight and level so there is no distortion in the conveyor.

All component pieces (or conveyor sections) should be placed in proper sequence before assembly is started.

3.4. INSTALLATION

For shop-assembled conveyors, units are match marked and shipped in the longest sections practical for shipment.

Field assembly can be accomplished by connecting marked joints in accordance with the packing list and/or drawing if applicable. In field erection, the mounting surfaces for supporting the conveyor must be level and true so there is no distortion in the conveyor. Shims or grout should be used when required. Frequently check for straightness during assembly.

For conveyor assemblies purchased as parts or merchandise, assemble according to the following procedure:

1. Place conveyor troughs in proper sequence with tail, bypass inlet, and head in proper location.
2. Connect the trough flanges loosely. Do not tighten bolts.
3. Align the trough bottom centerlines perfectly using piano wire (or equivalent); then tighten flange bolts.
4. Tighten all anchor bolts.

Note: 5. *In Figure 3.2, "A" dimension should be equal for full length of trough; bottom must be smooth through joints.*




Figure 3.2

- Note:**
6. Before connecting the top section of chain, loosen take-up as much as possible. Check sprocket alignment. Check set screws and bearing bolts for tightness.
 7. Connect top section for the chain. (On long conveyors, a come-a-long may be necessary.)

8. Adjust take-up to remove excess slack from chain making sure that adjustment screws have been tightened equally to prevent misalignment.
9. Install trough covers in the proper sequence. Handle covers with reasonable care to avoid warping or bending. Covers should be securely fastened.
10. Install drive at the proper location and in accordance with separate instructions provided.
11. Rotate conveyor by hand to ensure that no binding occurs.




Figure 3.3

Note: *Re-check assembly step if binding does occur.*

12. Check for proper direction of chain and flight travel after electrical connections have been made and before attempting to handle material.

Note: *All electrical work must be performed by a licensed electrician.*

13. If necessary, after lock out / tag out, reconnect electrical leads to reverse direction of material flow. Material should be pushed by the flight and attachment.
14. Attach all gates, feed chute, discharge chute, etc. and connect all safety devices and controls according to the assembly drawing for your conveyor, included as an insert in this manual. **Carefully test to ensure proper operation.**

3.5. MOTOR MOUNTS DRAG CONVEYOR ASSEMBLY

Refer to Figure 3.4 for descriptions of component parts.

1. Using the hardware provided, assemble uprights (the angled parts to which the reducer is fastened) to the u-shaped, rectangular bottom plate. Notice that there are eight slots cut into the plate.
2. Assemble the uprights in the innermost slots. The bottom plate may be mounted with the vertical flanges up or down (as shown in Figure 3.4).




Figure 3.4 Motor Mount Components

3. Snug bolts only, do not torque bolts at this time.
4. Fasten long threaded studs to the four corners of bottom plate using jam nuts, one on each side of the plate. Securely tighten these nuts, as they will not require any further adjustment.
5. Add one additional jam nut to each stud and thread approximately to the middle of the stud.
6. Assemble top motor plate (the flat rectangular plate with many holes) on top of the jam nuts.
7. Assemble the remaining jam nuts on studs to secure top motor plate.
8. Do not fully tighten these nuts yet.
9. The motor mount may be installed in position and in any of the mounting levels (M1, M2, M3) shown in Figure 3.5.




Figure 3.5

Note that the motor mount uprights attach to the input side of the reducer.

Table 3.1

	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			56T / A = .78	140T / A = 1.22	180T / A = 1.37	210T / A = 1.55	---
TA0107L	M1	17.2 - 21.0	17.2 - 21.0	18.2 - 22.0	19.0 - 22.8	---	---
	M2	19.6 - 23.4	19.6 - 23.4	20.6 - 24.4	21.3 - 25.1	---	---
	M3	22.0 - 25.8	22.0 - 25.8	23.0 - 26.8	23.7 - 27.5	---	---
	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			56T / A = .78	140T / A = 1.22	180T / A = 1.37	210T / A = 1.55	250T / A=1.56
TA1107H	M1	15.7 - 20.0	15.7 - 20.0	16.7 - 21.0	17.5 - 21.8	18.5 - 22.8	---
	M2	18.3 - 22.6	18.3 - 22.6	19.3 - 23.6	20.1 - 24.4	21.1 - 25.4	---
	M3	20.9 - 25.2	20.9 - 25.2	21.9 - 26.2	22.6 - 27.0	23.6 - 28.0	---
	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			56T / A = .78	140T / A = 1.22	180T / A = 1.37	210T / A = 1.55	250T / A=1.56
TA2115H	M1	18.5 - 22.2	18.5 - 22.2	19.5 - 23.2	20.3 - 24.0	21.3 - 25.0	---
	M2	21.6 - 25.3	21.6 - 25.3	22.6 - 26.3	23.3 - 27.0	24.3 - 28.0	---
	M3	24.6 - 28.3	24.6 - 28.3	25.6 - 29.3	26.4 - 30.1	27.4 - 31.1	---
	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			140T / A = 1.22	180T / A = 1.37	210T / A = 1.55	250T / A=1.56	280T / A=1.16
TA3203H	M1	19.8 - 23.9	20.8 - 24.9	21.6 - 25.6	22.6 - 26.6	23.3 - 27.4	---
	M2	23.3 - 27.3	24.3 - 28.3	25.0 - 29.1	26.0 - 30.1	26.8 - 30.8	---
	M3	26.7 - 30.8	27.7 - 31.8	28.5 - 32.5	29.5 - 33.5	30.2 - 34.3	---
	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			140T / A = 1.22	180T / A = 1.37	210T / A = 1.55	250T / A=1.56	280T / A=1.16
TA4207H	M1	22.6 - 26.7	23.6 - 27.7	24.4 - 28.4	25.4 - 29.4	26.1 - 30.2	27.1 - 31.2
	M2	26.8 - 30.8	27.8 - 31.8	28.5 - 32.5	29.5 - 33.5	30.3 - 34.3	31.1 - 35.3
	M3	30.9 - 34.9	31.9 - 35.9	32.6 - 36.7	33.6 - 37.7	34.4 - 38.4	35.4 - 39.4
	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"					
			180T / A = 1.37	210T / A = 1.55	250T / A=1.56	280T / A=1.16	320T / A=.38
TA5215H	M1	26.2 - 30.3	26.9 - 31.1	27.9 - 32.1	28.7 - 32.8	29.7 - 33.8	30.7 - 34.8
	M2	31.2 - 35.3	31.9 - 36.1	32.9 - 37.1	33.7 - 37.8	34.7 - 38.8	35.7 - 39.8
	M3	36.2 - 40.3	36.9 - 41.1	37.9 - 42.1	38.7 - 42.8	39.7 - 43.8	40.7 - 44.8

TA6307H	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"						
		180T / A = 1.37	210T / A = 1.55	250T / A=1.56	280T / A=1.16	320T / A=.38	360T / A=1.01	400T / A=.75
	M1	27.5 - 31.5	28.2 - 32.3	29.2 - 33.3	30.0 - 34.0	31.0 - 35.0	32.0 - 36.0	33.0 - 37.0
	M2	32.7 - 36.7	33.4 - 37.5	34.4 - 38.5	35.2 - 39.2	36.2 - 40.2	37.2 - 41.2	38.2 - 42.2
	M3	37.9 - 41.9	38.6 - 42.7	39.6 - 43.7	40.4 - 44.4	41.4 - 45.4	42.4 - 46.4	43.4 - 47.4

TA0107H	Mtg.	Motor Frame / Motor Shaft Offset Dimension "A"						
		56T / A = .78	140T / A = 1.22	180T / A = 1.37	210T / A = 1.37	250T / A = 1.56	---	---
	M1	17.7 - 22.0	17.7 - 22.0	18.7 - 23.0	19.5 - 23.8	20.5 - 24.7	---	---
	M2	20.3 - 24.6	20.3 - 24.6	21.3 - 25.6	22.1 - 26.4	23.1 - 27.4	---	---
	M3	22.9 - 27.2	22.9 - 27.2	23.9 - 28.2	24.6 - 29.0	25.6 - 30.0	---	---

3.6. INSTALLATION FOR TORQUE-ARM II SPEED REDUCER

1. Use lifting bracket to lift reducer.
2. Install the magnetic drain plug in the hole closest to the bottom of the reducer. Throw away the tape that covers the filter/ventilation plug in shipment and install plug in topmost hole. Of the 2 remaining plugs on the sides of the reducer, the lowest one is the minimum oil level plug.




Figure 3.6 Mounting Position

Table 3.2

Vent and Plug Locations					
1	2	3	4	5	6
Drain	Vent	Level	Plug	Plug	Plug

3. Mount reducer on driven shaft. See "Torque-Arm II Bushing Installation" on page 19 of this manual.
4. Install sheave on input shaft as close to reducer as practical. (See Figure 3.7)
5. Install torque arm and adapter plates reusing the reducer bolts. The adapter plates will fit in any position around the input end reducer.
6. Install torque arm on reducer and equipment using hardware provided (See Figure 3.8). Make sure that there is sufficient take-up in the turnbuckle for belt tension adjustment when using V-belt drive.

NOTICE

Unit is shipped without oil. Add proper amount of recommended lubricant before operating. Failure to observe this precautions could result in damage or destruction of the equipment.

7. Fill gear reducer with recommended lubricant.




Figure 3.7 Reducer and Sheave Installation




Figure 3.8

3.6.1. TORQUE-ARM II BUSHING INSTALLATION

WARNING	
	<p>To ensure that drive is not unexpectedly started, turn off and lock out or tag power source before proceeding. Remove all external loads from drive before removing or servicing drive or accessories. Failure to observe these precautions could result in bodily injury.</p>

STANDARD TAPER BUSHINGS:

1. One bushing assembly is required to mount the reducer on the driven shaft. An assembly consists of two tapered bushings, bushing screws and washers, two bushing backup plates and retaining rings, and necessary shaft key or keys. The driven shaft must extend through the full length of the reducer.
2. Install one bushing backup plate on the end of the hub and secure with the supplied retaining ring. Repeat procedure for other side.
3. Place one bushing, flange end first, onto the driven shaft and position per dimension "A", as shown in Table 3.3. This will allow the bolts to be threaded into the bushing for future bushing and reducer removal.
4. Insert the output key in the shaft and bushing. For ease of installation, rotate the driven shaft so that the shaft keyseat is at the top position.
5. Mount the reducer on the driven shaft and align the shaft key with the reducer hub keyway. Maintain the recommended minimum distance "A" from the shaft bearing.
6. Insert the screws, with washers installed, in the unthreaded holes in the bushing flange and align with the threaded holes in the bushing backup plate. If necessary, rotate the bushing backup plate to align with the bushing screws. Tighten the screws lightly.
7. Place the second tapered bushing in position on the shaft and align the bushing keyway with the shaft key. Align the unthreaded holes in the bushing with the threaded holes in the bushing backup plate. If necessary, rotate the bushing backup plate to align with the bushing holes. Insert bushing screws, with washers installed in the unthreaded holes in the bushing. Tighten screws lightly.
8. Alternately and evenly tighten the screws in the bushing nearest the equipment to the recommended torque. Repeat procedure on outer bushing.




Figure 3.9 Minimum Recommended Dimensions

Table 3.3 Bushing Screw Information and Minimum Clearance for Removal

Reducer Size	Fastener Size	Torque in Ft-lb.	A
TA0107L	5/16-18	17 -15	1.08
TA1107H	5/16-18	17 - 15	1.20
TA2115H	3/8-16	30 - 27	1.20
TA3203H	3/8-16	30 - 27	1.20
TA4207H	3/8-16	30 - 27	1.48
TA5215H	1/2-13	82 - 42	1.81
TA6307H	1/2-13	82 -42	1.81

3.7. TORQUE-ARM II BELT GUARD INSTALLATION

WARNING	
	<p>To ensure that drive is not unexpectedly started, turn off and lock out or tag out power source before proceeding. Remove all external loads from drive before removing or servicing drive accessories. Failure to observe these precautions could result in bodily injury.</p>

WARNING	
	<p>Ensure that all guards are properly installed before proceeding. Exercise extreme care to avoid contacting rotating parts. Failure to observe these precautions could result in bodily injury.</p>

1. Move belt guard and hardware from box and verify all parts are available. The belt guard assembly consists of one back cover, one front cover, two brackets, and necessary hardware.
2. Using the hardware provided, assemble the two brackets to the back cover as shown in Figure 3.11. Note that the brackets are mounted so that the angles of the brackets are mounted to the inside. Do not fully tighten these bolts.
3. Position back cover over the motor shaft and reducer input shaft. The long slot in the back cover fits over the motor shaft.
4. Align the back cover assembly to the Torque-Arm II motor mount and attach using four cap screws, washers, and nuts. Securely tighten the brackets to the motor mount and back cover.
5. Install motor and reducer sheaves. Install belts and adjust accordingly.
6. Align hinges on front cover to pins on back cover and assemble.

7. Close cover and secure with two cap screws and washers.
8. Check machine for proper operation.




Figure 3.10




Figure 3.11

4. Operation

Warning: Before continuing, please reread the safety information relevant to this section in the safety section of this manual. Failure to follow the safety instructions can result in serious injury, death, or property damage.

Important: Do not operate Drag Conveyors unless the housing completely encloses the moving elements and power transmission guards are in place.

4.1. PRE-OPERATION

Before operating the Drag Conveyor check to ensure:

1. Lubricate all bearings and drives.
2. Interior: Check the interior of the Drag Conveyor to ensure all tools, foreign materials, and other obstructions have been removed.
3. Hardware: Check that all hardware is secure.
4. Set screws: Check all set screws on pulleys, bearings, sprockets, sheaves, gear reducers, etc. Although some set screws may have been installed at the factory, shipment, handling, and installation could have loosened them. We cannot be responsible for damage caused by loose set screws.
5. Level: Check that the head shaft is level.
6. Drive: Check for proper rotation of motor and gear reducer.
7. Tail: Adjust take-up screws so that there is no slack in the chain and so that the tail shaft is level.
8. Lubrication: Lubricate all bearings and drives according to service instructions. Bearings and gear reducers are normally shipped without lubricant. Refer to bearing and gear reducer manufacturer's service instructions for recommended lubricant.
9. Guards: Install all covers, guards, safety devices or controls, and any interlock to other equipment and ensure they are operating properly.

4.2. START-UP

Operate the empty conveyor for several hours as a break-in period. Look for bearing heat, unusual noises, or drive misalignment. Should any of these occur, check the following and take corrective steps.

1. When anti-friction bearings are used, check for proper lubrication. Insufficient or excessive lubricant will cause high operating temperatures.

NOTICE

Loose chains and misalignment of troughs and sprockets can require excessive maintenance and cause poor life expectancy.

2. Check assembly and mounting bolts and set screws; tighten if necessary.

After running the conveyor, stop it, lock out all power, and check discharge to ensure it is clear and material flow through the discharge will not be impeded in any way.

3. Restart the conveyor and gradually feed material. Gradually increase feed rate until the design capacity is reached.

Important: *Do not overload conveyor. Do not exceed conveyor speed, capacity, material density, or rate of flow for which the conveyor and drive were designed.*

4. Cut off feed and allow the conveyor to empty. Lock out power supply. Check all bolts and all alignments. Realign as necessary, tighten all bolts, and check chain adjustment.
5. Check motor amperage frequently.
6. Check chain tension periodically. It may be necessary to readjust chain tension after running material in the conveyor.
7. If the conveyor will not be operated for a prolonged period of time (one month or longer), operate until cleared of all material. This is particularly important when the material conveyed tends to harden, become more viscous or sticky, or spoils if allowed to stand for a period of time.

4.3. GENERAL

- Run the conveyor empty for a few minutes periodically to check for excessive vibration, loose fasteners, security of covers and guards, noise, and bearing and drive temperature.
- Always operate the conveyor with covers, guards, and safety labels in place.
- Always practice good housekeeping and keep a clear view of the conveyor loading, discharges, and all safety devices.

DANGER	
	<p>Rotating parts hazard!</p> <p>To avoid serious injury or death: Keep body, hair, and clothing away from rotating pulleys, belts, chains, and sprockets. Keep all guards in place and in good working order. Lock out power before removing guard.</p>

5. Maintenance

Warning: Before continuing, please reread the safety information relevant to this section in the safety section of this manual. Failure to follow the safety instructions can result in serious injury, death, or property damage.

CAUTION	
	<p>Before performing any internal inspections or maintenance, ensure that a mechanical lockout is in place on the motor starter.</p>

Establish routine periodic inspections of the entire conveyor to ensure continuous maximum operating performance.

Replacement parts can be identified from a copy of the original packing list, invoice, or drawing.

PERIODIC INSPECTIONS SHOULD BE MADE ON THE FOLLOWING:

Trough	Check for wear and alignment. Tighten all bolts.
Shafts	Check for wear.
Flights	Check edges for wear or damage.
Bolts And Nuts	Check for wear and tightness.
Seals	Check for leakage, adjustment, and wear.
Bearings	Check for lubrication and noise. Refer to bearing manufacturer's service instructions for recommended lubricant.
Sprockets	Check for wear and alignment.
Chain	Check for worn pins and damaged sidebars.
Take-up	Check chain tension. Adjust take-up to remove excess slack from chain making sure that adjustment screws have been tightened equally to prevent misalignment. If take-up is fully adjusted, a link of chain will need to be removed.
Gear Reducer	Check for oil level and noise. Refer to Gear Reducer manufacturer's service instructions for recommended lubricant.
V-belt/chain Drive	Check belt/chain tension and adjust as required.
Guards	Check for oil level (if applicable). check nuts and bolts for tightness.

TO REPLACE OR SHORTEN A CONVEYOR CHAIN SECTION:

1. Lock out power.
2. Locate the cotter pin section of the chain and rotate the chain until it is on the top.
3. Loosen the take-up fully, remove the cotter pin, and remove the desired length.
4. Connect top section for the chain. (On long conveyors, a come-a-long may be necessary.)

5. To reassemble, follow the above steps in reverse order.

5.1. TORQUE-ARM II SPEED REDUCER MAINTENANCE

5.1.1. BUSHING REMOVAL FOR STANDARD TAPER BUSHINGS

1. Remove bushing screws.
2. Place the screws in the threaded holes provided in the bushing flanges. Tighten the screws alternately and evenly until the bushings are free on the shaft. For ease of tightening screws make sure screw threads and threaded holes in the bushing flanges are clean.
3. Locate two (2) wedges at 180° between the bushing flange and the bushing backup plate. Drive the wedges alternately and evenly until the bushing is free on the shaft.
4. Remove the outside bushing, the reducer, and then the inboard bushing.

5.1.2. LUBRICATION

Important: *Because reducer is shipped without oil, it is necessary to add the proper amount of oil before operating reducer. Use a high-grade petroleum base rust and oxidation inhibited (R&O) gear oil - see tables. Follow instructions on reducer warning tags, and in the installation manual.*

Under average industrial operating conditions, the lubricant should be changed every 2500 hours of operation or every 6 months, whichever occurs first. Drain reducer and flush with kerosene, clean magnetic drain plug and refill to proper level with new lubricant.

CAUTION	
	Too much oil will cause overheating and too little will result in gear failure. Check oil level regularly. Failure to observe this precaution could result in bodily injury.

Under extreme operating conditions, such as rapid rise and fall of temperature, dust, dirt, chemical particles, chemical fumes, or oil sump temperatures above 200°F, the oil should be changed every 1 to 3 months, depending on severity of conditions.

Table 5.1

Reducer Size	Approx. Volume of Oil to Fill Reducer to Oil Level Plug	
	Position B	
	Qt	L
TA0107L	0.5	0.5
TA1107H	0.7	0.7
TA2115H	1.1	1.1
TA3203H	1.5	1.4
TA4207H	2.5	2.4
TA5215H	4.7	4.4
TA6307H	5.5	5.2
TA7315H	10.8	10.3

Note: Oil quantity is approximate. Service with lubricant until oil runs out of oil level hole.

Table 5.2

ISO Grades For Ambient Temperatures of 50° F to 125°F.								
Output RPM	Torque-Arm II Reducer Size							
	TA0107L	TA1107H	TA2115H	TA3203H	TA4207H	TA5215H	TA6307H	TA7315H
301- 400	320	320	320	220	220	220	220	220
201-300	320	320	320	220	220	220	220	220
151- 200	320	320	320	220	220	220	220	220
126 -150	320	320	320	220	220	220	220	220
101- 125	320	320	320	320	220	220	220	220
81- 100	320	320	320	320	320	220	220	220
41 - 80	320	320	320	320	320	220	220	220
11- 40	320	320	320	320	320	320	320	320
1 -10	320	320	320	320	320	320	320	320

Table 5.3

ISO Grades For Ambient Temperatures of 15°F to 60°F .								
Output RPM	Torque-Arm II Reducer Size							
	TA0107L	TA1107H	TA2115H	TA3203H	TA4207H	TA5215H	TA6307H	TA7315H
301 - 400	220	220	220	150	150	150	150	150
201 - 300	220	220	220	150	150	150	150	150
151 - 200	220	220	220	150	150	150	150	150
126 - 150	220	220	220	150	150	150	150	150
101 - 125	220	220	220	220	150	150	150	150
81 - 100	220	220	220	220	220	150	150	150
41 - 80	220	220	220	220	220	150	150	150
11 - 40	220	220	220	220	220	220	220	220
1 - 10	220	220	220	220	220	220	220	220

Note: Assumes auxiliary cooling where recommended in the catalog.

Pour point of lubricant selected should be at least 10°F lower than expected minimum ambient starting temperature.

Extreme pressure (EP) lubricants are not necessary for average operating conditions. When properly selected for specific applications, TORQUE-ARM II backstops are suitable for use with EP lubricants.

For reducers operating in ambient temperatures between -22°F (-30°C) and 20°F (-6.6°C) use a synthetic hydrocarbon lubricant, 100 ISO grade or AGMA 3 grade (for example, Mobil SHC627). Above 125°F (51°C), consult Union Iron (217) 429-5148 for lubrication recommendation.

Mobil SHC630 Series oil is recommended for high ambient temperatures.

5.2. DRAG CONVEYOR EXTENDED SHUTDOWN/STORAGE

If the conveyor will be shutdown for more than one month, perform the following:

1. Remove all foreign material from the conveyor and check that the surface coatings are in good order.
2. Lubricate and protect all bearings and drives according to the manufacturer's instructions.
3. Rotate the gear reducer periodically according to the manufacturer's instructions.
4. Protect the conveyor from weather, moisture, and extreme temperatures as required. Do not use plastic or other coverings that promote condensation under the covering.
5. Coat all exposed metal surfaces with rust preventative oil according to the manufacturer's instructions.
6. Prior to start-up, perform the installation and operation instructions in this manual.

5.3. TORQUE-ARM II SPEED REDUCER STORAGE

During periods of long storage, or when waiting for delivery or installation of other equipment, special care should be taken to protect a gear reducer to have it ready to be in the best condition when placed into service.

By taking special precautions, problems such as seal leakage and reducer failure due to lack of lubrication, improper lubrication quantity, or contamination can be avoided. The following precautions will protect gear reducers during periods of extended storage:

PREPARATION:

1. Drain oil from the unit. Add a vapor phase corrosion inhibiting oil (VCI-105 oil by Daubert Chemical Co.) in accordance with Table 5.4.
2. Seal the unit airtight. Replace the vent plug with a standard pipe plug and wire the vent to the unit.
3. Cover all unpainted exterior parts with a waxy rust preventative compound that will keep oxygen away from the bare metal. (Non-Rust X-110 by Daubert Chemical Co. or equivalent)
4. The instruction manuals and lubrication tags are paper and must be kept dry. Either remove these documents and store them inside, or cover the unit with a durable waterproof cover which can keep moisture away.
5. Protect reducer from dust, moisture, and other contaminants by storing the unit in a dry area.

6. In damp environments, the reducer should be packed inside a moisture-proof container or an envelope of polyethylene containing a desiccant material. If the reducer is to be stored outdoors, cover the entire exterior with a rust preventative.

When placing the reducer into service:

1. Fill the unit to the proper oil level using a recommended lubricant. The VCI oil will not affect the new lubricant.
2. Clean the shaft extensions with petroleum solvents.
3. Assemble the vent plug into the proper hole.

Follow the installation instructions provided in this manual.

Table 5.4 Quantities of VCI #105 Oil

Reducer Size	Quantity (Ounces / Millilitre)
TA0107L	1 / 30
TA1107H	1 / 30
TA2115H	1 / 30
TA3203H	1 / 30
TA4207H	1 / 30
TA5215H	2 / 59
TA6307H	2 / 59
TA7315H	3 / 89

VCI #105 and #10 are interchangeable.

VCI #105 is more readily available.




Figure 5.1

6. Troubleshooting

PROBLEM	CAUSE	REMEDY
Premature trough failure	Gauge too light	Increase thickness. Consult Union Iron for recommendations
	Worn flights	Replace flights
	Excessive chain speed	Check chain speed
Accelerated flight wear	Excessive heat	Change flight material. UHMW is limited to 175°F
	Speed too high	Reduce speed. Consult Union Iron to determine proper chain speed
	Foreign objects	Remove foreign objects
Chain breakage	Worn chain	Replace chain if worn
	Take-up is loose	Adjust take-up (See Maintenance Section)
	Obstruction in conveyor	Remove obstruction
	Sprocket misalignment	Align sprockets
	Plugged discharge	Remove plug
	Overloading conveyor	Regulate feed into conveyor
Drive shaft breakage	Excessive torque	Recalculate horsepower requirements
	Insufficient torque capacity.	Increase diameter of shaft Change shaft material
	Obstruction in conveyor	Remove obstruction
	Overloading conveyor	Regulate feed into conveyor
Bearing Failure	Material getting into bearing	Add or upgrade seal to keep material out of bearing Change to outboard bearing
	Insufficient/excessive lubrication	Lubricate properly (See Maintenance Section.)
Motor/heaters overload	Amp demand excessive for motor	Recheck horsepower calculations Check material characteristics Check capacity Regulate feed
Drastic capacity loss	Missing flights	Replace flights

LIMITED WARRANTY

Seller warrants that all of the goods sold hereunder will conform to their description in Seller's published literature current at the time the Buyer's order is accepted, that Seller will use good material and workmanship in the manufacture of such goods, and that such goods will conform to applicable laws and regulations regarding purity.

Seller will repair or replace, at its discretion, any nonconforming goods (or refund their purchase price at Seller's option), but only if Seller receives written notice of nonconformity within 60 days after shipment and Buyer's remedies hereunder are expressly so limited.

Seller makes no other warranties of any kind with respect to such goods or any part thereof, express or implied. All implied warranties of merchantability and fitness for a particular purpose are hereby disclaimed by seller and excluded from this agreement, and such goods are sold "as is" and with all faults.

Seller will have no liability for consequential damages of any kind, including damages arising from bodily injury or the loss of use of such goods or other property. Buyer releases all claims for such damages, whether based on contract, warranties, strict liability, or negligence.



HSI

part of the Ag Growth International Inc. group

602 S. 27th Street, P.O. Box 1038

Decatur, IL 62525 USA

Phone: (217) 429-5148

Fax: (217) 429-5149

website: www.hsisystems.com

© Ag Growth International Inc. 2013

Printed in Canada

